

Upgrade programu AxSys

Po nainštalovaní programu vykonajte nasledovné zmeny

Upon download of this software, please install this software & do the following modification :

The image shows a Windows XP desktop with two windows open. The left window is 'AxSys - Access Control System' showing the file explorer view of the installation directory 'C:\Program Files\AxSys - Access Control System'. The right window is 'AxSys - WordPad' showing the contents of the 'AxSys.DAT' file. Three callout boxes provide instructions for upgrading the software.

1. Open AxSys program folder look for file : AxSys.DAT

2. Open " AxSys.DAT " & edit the content.

**3. Change the 3 delay parameter to :-
PollDelay (ms) = 200
SendDelay (ms) = 100
RecvDelay (ms) = 100**

```
DETECTPANEL=Yes
RELOADCARDDB=No
RELOADSETTING=No
CONTROLLERSTYPE=0
RECORDFORMAT=0
DEDUCTLUNCHHOUR=No
LUNCH_S1=1230
LUNCH_E1=1330
TRXSVR_PORT=5000
TRXSVR_ENABLE=Yes
CARPARKACCESS=No
TIMEATTENDANCE=No
SENDCARDONTZZERO=No
REFRESHCARDDB=HH:MM
PCBPANEL=0
PollDelay (ms) = 100
SendDelay (ms) = 50
RecvDelay (ms) = 50
SYSTEMTRAY=No
TMSREADER=No
FPSENDINGDELAY
DEBUG_NESTING=
MAP_OUT_AS_IN=
COMPORT_DELAY=
TCP_IP_DELAY=50
RETRYCOUNT=10
PUNISHCOUNT=20
ALARMWAVEFILE=
FINDCARDONINVALID
FIRERELEASEBYBUS=No
INOROUTREADER=No
```